

## How to program your Automatic Tank Drain System

Model: SML-D100



**Manual Drain:** This option allows you to open the release valve. By pressing and holding the “MANUAL DRAIN” button, the air release valve will remain open, once you release the button the valve will close.

---

**Set:** This option allows you to set the auto release timer.

**Step 1.** Hold the “SET” button for 5 seconds, the LED light will change from blinking to solid.

**Step 2.** By pressing the “ZERO” button the digital display will reset to 0 hours.

**Step 3.** By pressing the “TIME” button you can adjust the timer, each digit represents 1 hour. (Example; if you select 3, the release valve will open every 3 hours automatically)

**Step 4.** Press the “SET” button to save the new time. The LED light will now change from solid to blinking.

**Warning: After finishing set up procedure, you must unplug power plug for 1 minute and reconnect.**

---

**How to increase your release valve (once timer goes off) In case you would like the release valve to remain open for a longer period of time.**

**Step 1.** Hold the “SET” button for 5 seconds, the LED light will change from blinking to solid.

**Step 2.** Hold the “MANUAL DRAIN” button for 8 seconds

**Step 3.** By pressing the “TIME” button you can increase the time the valve remains open, each digit represents 1 second. If you go to high, you can press the “ZERO” button to restart. (Example if you select 10, once the timer goes off; the release valve will remain open for 10 seconds)

**Step 4.** Press the “SET” button to save the new time. The LED light will now change from solid to blinking.